



PN08






创建新项目


- 打开现有项目
- 创建新项目
- 移植项目
- 关闭项目



项目名称 :	<input type="text" value="profinet"/>
路径 :	<input type="text" value="C:\Users\lool\Documents\Automation"/> ...
版本 :	<input type="text" value="V15.1"/>
作者 :	<input type="text" value="xxx"/>
注释 :	<input type="text"/>




" N " " GSD

(D)"












此外修改IP地址, 修改后需要下载程序。

IP需要与从站在同一网段, 从站IP地址可在PROFINET








ÚƆèì

ÚƆèì



设备概览

模块	机架	插槽	I 地址	Q 地址	类型	订货号	固件	注释
PN08	0	0			Huceed, PN08	PN08		
Interface	0	0 X1			PN08			
AM06 4AI2AO*12Bit_1	0	1	68...75	64...67	AM06 4AI2AO*12Bit	H7 288-3AM06-0AA0		
	0	2						
	0	3						
	0	4						
	0	5						
	0	6						
	0	7						
	0	8						
	0	9						
	0	10						
	0	11						
	0	12						

